




Maintenance and cleaning:

Wipe with a soft damp cloth. Immediately wipe excess water with a dry cloth. Moisture might cause the lacquer to crack. Any use of abrasive cleaners or solvents will damage the lacquer. The color of the product might change in exposure to sun light.

Designed and patented by Br. Ekornes Industri AS, Norway

Produced and distributed by




IMPORTANT!! KEEP FOR FUTURE REFERENCE

According to standard EN 14988:2017 only in combination with safety kit for Kiddo children's chair.

Assembly instructions Kiddo children's chair



Make sure that the pivot bolt facing the floor hits the pivot hole in the back leg placed on the floor.



Apply hard pressure on the front leg with your knee and guide the pivot bolt into the pivot hole in the back leg closest to you. You may now raise up the chair and once more check that both pivot bolts are properly inserted into the pivot holes.



Screw in one bolt on each side and tighten it properly.



Insert the seat at an angle, turn it until it is level and let it go into a suitable groove on both sides. When the seats front edge is lowered you should hear it snap into locking position. Repeat the procedure on the foot rest. The seat has a "keyhole" underneath, the foot rest has nothing.



To adjust the height of the seat; stand behind the chair, press both plastic lockers and raise the front end. You can now slide the seat up or down. When the desired height is reached, lower the front end until it snaps into lock. Same procedure on the foot rest.



Warning

Do not leave the child unattended!

Small children must always use the chair in combination with appropriate safety kit. Make sure that every part of the safety kit is correctly fitted: The harness attached to the chair, crotch belt under the seat, waist belt attached to the chair and tightly around the child.

Do not use the chair unless all parts are correctly fitted.

Always place the chair on a level floor surface and make sure there is room for the chair to be pushed back.

The child must be able to sit up by itself before being placed into the chair. Recommended use from 6 months age.

Do not use the chair if any parts are damaged or missing. Make sure not to place the chair close to small objects, toxic material, open fire or other sources of strong heat such as stoves, electric heaters and so on. This may cause serious injury or death to the child.

WARNING: Prevent your child from climbing on the product

CLAIMS:

The customer has the right to claim the product according to the rules in the country where it is sold. This can vary from country to

Any claims must be timely filed to the seller of the product. Original receipt and documentation of the reason for claim must be available.

The product is intended for children able to sit up unaided and up to 3 years or a maximum weight of 15 kg